



ADR Cooling for IR Telescopes and Detectors

***Peter Shirron, Michael DiPirro,
Edgar Canavan, Michael Jackson and James Tuttle
NASA/Goddard Space Flight Center***

***Session B
Cooling Systems for Large Telescopes
June 7, 2004***

Introduction

■ *Future Needs*

- *Detector Cooling*
 - *Up to 10 μ W at 50 mK*
 - *Cooling to 20 mK*
- *Cooling for Large Telescopes*
 - *10-100 mW at 4 K*
- *Cryogen-free, high efficiency*


■ *ADR Development*

- *Primarily for low temperature detector cooling*
 - *First flight ADR will launch on Astro-E2 Feb. 2005*
- *Multi-stage configuration makes operation to 30+ K possible*
- *Talk emphasizes*
 - *Configurations for low, intermediate and high T*
 - *Technology development needed*




ADR Cycle (Carnot)


Recycling



- $B=0$
- $T_{salt} \leq T_{sink}$




- Magnetize salt until $T_{salt} \geq T_{sink}$
- Turn on heat switch




- Magnetize to full field
- Wait until $T_{salt} \sim T_{sink}$
- Turn off heat switch

Operational Mode




- Demagnetize until T_{salt} reaches operating point
- Slowly demagnetize to maintain stable T as salt absorbs heat

Continuous ADR



- ***Load is cooled by a “continuous” stage***
- ***Stages 2-4 cascade heat to the heat sink***
- ***Benefits***
 - *Solid state, no moving parts, no gravity dep.*
 - *Continuous cooling*
 - *1-2 orders of magnitude higher cooling power per unit mass*
 - *Scalable to higher cooling power*
 - *Expandable to higher heat sink temperature*


Recycling Sequence



Salt Pills/Refrigerants

- **Low temperature refrigerants**

- Hydrated salts
- Thermal bus occupies ~25% of salt pill volume
- Very high thermal conductance even at low temperature



Salt Pill
(100 gram CPA)




- **High temperature refrigerants**

- Single or poly-crystal
- GGG , GdLiF_4 , GdF_3 , ...
- Transition temperatures of .5-2 K

Passive Gas-Gap HSs


- ***Traditional GGHS Has Separate Getter Attached to Warm End of Switch***
- ***Passive GGHS Has Getter Housed Within Switch at Cold End (For ADR Use)***




PGGHS Performance

- *Transition temperature can be tuned by gas species and amount*
 - Gas latent heat: He-3 (~.2 K), He-4 (~.8 K), H₂ (~6 K), Ne (~10 K), ...
 - Gas adsorption
 - Substrates: frozen gases, metals, zeolite, charcoal


<u>Gas/Substrate</u>	<u>T_{ON/OFF}</u>
³ He/ ³ He	0.2
³ He/H ₂ /Sintered SS	1.0
³ He/Sintered SS	4.0
H ₂ /H ₂	5.2
Ne/Ne	11
³ He/Charcoal	13




Prototype 4-Stage CADR



- **4.2 K heat sink**
- **Total mass of 7.7 kg**
- **Magnets are fully shielded**
- **Operation is fully automated**





4-Stage Cycling



Temperature Stability


- *Temperature stability at 100 mK is 5-6 μ K rms (electronics noise)*
- *Less stable at lower temperature*
 - *Transients as large as 100 μ K*



CADR Configuration for Constellation-X




- **Basic 4-stage CADR for 0.05 to 6 K operation**
- **Additional stage cools SQUID amplifiers and 1 K shield**



Constellation-X Cryogenic System Layout




- ***X-Ray Microcalorimeter Spectrometer (XMS) Detector assembly***
 - *32 x 32 TES Detector arrays and first stage SQUID amplifiers at 50 mK*
 - *Second stage SQUID array amplifiers at 1 K*
- ***Continuous ADR (CADR)***
 - *~10 kg*
- ***Cryocooler***
 - *200 mW at 18 K*
 - *20 mW at 6 K*
 - *Goal of 4 K operation*





4-30K ADR Configuration

- **Optimal system uses 8 stages to span 4-30 K**
 - *Two banks of magnets synchronously driving 4 stages each*
- **Stages connected by passive gas-gap heat switches**




Cooldown and Cycling



- ***Model run for cooling powers up to 10 mW***
- ***Efficiency ~35% (of Carnot)***



Cooler Comparison



■ *Courtesy of Dean Johnson/JPL*


Toroidal Configuration

- *Magnetically self-shielding*
- *Low mass per cooling power*



Technology Development

- ***Magnets operate at heat sink temperature***
 - *Operation above 5-6 K operation requires shift from NbTi*
 - *Possibilities include Nb₃Sn, MgB₂, HTS materials*
 - *Lead conduction dominates thermal design -> low current*
 - *Minimize current and number of magnets*
 - *Nb₃Sn and HTS difficult to fabricate in small cross-section*
- ***SBIR with Superconducting Solutions, Inc. to develop 3-4 T magnets working at 12+ K using Nb₃Sn***
 - *Uses 0.2 mm wire in “react and wind” technique*



Summary



- ***ADRs are very versatile***
 - *Wide temperature range: below 50 mK to above 30 K*
 - *ADRs are ideal for space use*
 - *High efficiency compared to other coolers*
- ***Multi-stage architecture***
 - *Increases performance*
 - *Lower mass, higher cooling power*
 - *Lower operating temperature and higher sink temperature*
 - *Allows cooling stages to be distributed*
- ***Combined high and low temperature systems will provide cooling solution for detectors and telescope***
- ***Presently working to implement a 4-10 K version of multi-stage ADR to be coupled with existing 50 mK system***