

High Resolution Direct Detection IR Spectroscopy

John Mather

JWST Senior Project Scientist

6/9/04


High Resolution Spectrometer Types

- Fabry-Perot imaging tuned filter, multiple stages, high order. Excellent for known small wavelength range, wide field, or ultra resolution in small volume
- Very large grating - first order, linear spectrum, can be combined with object selector or long slit. Excellent for large linear array detectors, size $> R$
- Crossed echelle and first order gratings, 2-D spectrum, good for point source, good for 2-D array detectors

High R Spectrometers


- Michelson imaging spectrometer, capable of imaging
 - good for wide field imaging spectroscopy
 - superior for small arrays of detectors that can't reach photon noise with narrow bandwidth
- Hybrids of imaging interferometer (FPI or Michelson) with dispersive system to beat down photon noise and gain spectral multiplexing with large detector arrays
- Heterodyne spectrometer
 - Superior for long wavelengths, very high R
 - Quantum noise limit = 1 photon/Hz/sec

High Resolution Fabry-Perot




Imaging, tunable, resonant filter, requires synchronized tuning. Can make plates reflective with multilayer dielectric coatings or with capacitive and inductive meshes. Spectral resolution = $\lambda/\Delta\lambda \sim \text{mean path difference} / \lambda = S/(\lambda(1-R))$

Imaging Michelson Spectrometer



Multi-Folded Michelson



$$\text{Path Length Change} = 32 * \text{motion}$$